



NOTES:  
 1. USE #2 TYPE B THREAD FORMING SCREWS TO INSTALL THE CIRCUIT CARD ASSEMBLY.

**PACITEC®**  
 1-610-361-4231

**XPM**

VISIT **PACITEC®**  
 ON THE WORLD WIDE WEB  
[www.pacitecenclosures.com](http://www.pacitecenclosures.com)

COLOR / MATERIAL / CODE		
COLOR	94HB	94V-0
BLACK	000	028
PC BONE	039	060

INSERT AREAS ARE SECTIONS IN OUR TOOLS THAT CAN BE REMOVED AND REPLACED WITH CUSTOMER SPECIFIC DETAILS

DRAWING NUMBER	REV
86778	B