



NOTES:

- USE #4 TYPE "B" THREAD FORMING SCREWS X .25 [6.35] OR .31 [7.94] TO ATTACH PC BOARD.

**PACNTEC**<sup>®</sup>  
1-610-361-4231

**FXT-2535**

VISIT **PACNTEC**<sup>®</sup>  
ON THE WORLD WIDE WEB  
[www.pactecenclosures.com](http://www.pactecenclosures.com)

| COLOR / MATERIAL CODE |      |      |
|-----------------------|------|------|
| COLOR                 | 94HB | 94VO |
| BLACK                 | 000  | 028  |
| P.C.BONE              | 039  | 060  |

INSERT AREAS ARE SECTIONS IN OUR TOOLS THAT CAN BE REMOVED AND REPLACED WITH CUSTOMER SPECIFIC DETAILS

| DRAWING NUMBER | REV |
|----------------|-----|
|                |     |